

PRODUCT CARE

How to care for your Clarus product.

ERASING AND CLEANING



- All Clarus glassboards are nonporous and will never stain or ghost
- Clean glass using standard liquid or foam glass/window cleaner
- Periodically clean the glass with standard glass/window cleaner to maintain a pristine look
- Clean frames with mild soap, water, and cloth
- Do not use Expo cleaner, as it can leave an unsightly film on the glass surface

MARKER SELECTION

- Clarus glassboards are compatible with dry-erase, permanent,
 chalk, neon markers, and more
- For a premium writing experience, Clarus offers a collection of recommended markers at clarus.com/accessories

NEED ADDITIONAL HELP?

If you have questions about product care or anything else, feel free to contact us at info@clarus.com. We're here to ensure you have the best experience possible.



READY TO ORDER?

Visit <u>clarus.com/quote</u> to start your next project.