

Product Care Guide



Erasing & Cleaning Glass

- + empowerED™ products are compatible with any marker. Dry-erase and paint markers can be wiped off using a simple eraser or dry cloth. Permanent markers may be removed using any standard glass cleaner.
- + Periodic cleaning of your empowerED product may be performed using glass cleaner on the front side of the glass board(s). Frames can be wiped clean with a cloth, or mild soap and water as needed.

Marker Selection

- + You may use any type of writing instrument, including but not limited to: permanent markers, chalk/grease markers, neon markers or dry-erase markers.

Cleaning Slat Wall

- + We recommend cleaning your slat wall with a damp cloth limiting water and harsh chemicals.

Cleaning Tack Board

- + We recommend cleaning your tack board with mild soap and warm water.